

Notes:

- o/ All panels 12mm, high quality multi-ply recommended
- 1/ vent spacer is ideally a dissimilar material, ie mdf, solid wood
- 2/ brace shape is only suggestive -- prime purpose is to brace driver, it needs to be about 35-40% holes. (ie if you have to mount a terminal cup in the middle, you'll want to make sure the brace allows clearance), It is intentionally just off centre.
- 3/ Don't forget to angle cut the back of the driver cut-out to give it breathing room
- 4/ All internal panels lined with ~1/2" (12mm) wool felt (preferred), 3/4" (19mm) poly-fluff batting, or 1" (25mm) fiberglass and the volume filled with very well teased polyfluff, less dense around the back of the driver.

